



FGS  
METALWORK

FGS  
STRUCTURAL

THE  
FENCE&GATE  
SOLUTION

# MANUAL RELEASE PROCEDURE

## TOUSEK TPS 6 Speed




In case of a power failure or other defect the drive pinion can be disengaged from the gearmotor as follows::


- Switch off power supply
- Slide key-cover slightly to the front and turn it away. Insert the key and turn it clockwise to its limit stop. Now the drive pinion can be disengaged from the gearmotor with the lever (3) and the gate can be moved manually. .



**Important:** To return to normal motor operation please turn the lever back to its locked position and slowly move the gate manually in its travel direction until you can hear that the gearing has re-engaged!



locked



unlocked

